Final Doublet Stability and in-detector Interferometry MONALISA

David Urner
Oxford University

MONALISA MONitoring ALIgnment and

Stabilisation with high Accuracy


- Is an interferometric metrology system for continuous monitoring of position critical accelerator components
- Consists of a fixed network of evacuated interferometric distance meters with nanometre type resolutions over O(10m)

MONALISA at ILC


- Survey and initial alignment required.
- Working alignment needs to be maintained / restored.
 - between trains
 - 200 ms is long enough for several 100 nm movement
 - Take into account long term drifts
 - after push-pull events:
 - IR hall floor <u>will move</u> after rolling two heavy detectors
 - Restore luminosity quickly after shutdown periods
- A position monitoring system of critical elements is your friend.

Main Component: CSM


(Compact Straightness Monitor)



- 6D position transferred from left to right
 - Integral use of sturdy endplates required.
 - Relative measurements O(1nm)
 - To understand geometry absolute measurement O(1μm)



Interferometer operation



Phase = 2π (Optical Path Distance) / Wavelength

$$\Phi = 2\pi D / \lambda$$
$$= 2\pi D (v / c)$$

frequeny scanning

$$\Delta D = (c/2\pi v) \Delta \Phi$$

Fixed Frequency Interferometry


$$D = (c/2\pi) (\Delta\Phi/\Delta nu)$$

$$D = R (\Delta\Phi/\Delta\theta)$$

$$R = (c/2\pi) (\Delta\theta/\Delta nu)$$


Frequency Scanning Interferometry

Interferometer operation





Distance meter


- Measurement Frequencies:
 - FFI: up to 10kHz
 - FSI: up to 1Hz
- Long term stability determines low frequency behaviour
 - For FSI given by quality of reference interferometer
 - For FFI we are building a system to lock the laser frequency to spectral feature of rubidium.
- Advantage of interferometric measurement system is fairly low cost per line.
 - Use of telecom frequency allows use of cheap commercial hardware.
 - Cheap amplification of light.




Access to QD0 (ILD)








Ideal Case: Direct View of QD0



Separation of Tasks: No direct view



How to go from here

- Need real engineering
 - Who is doing what?
 - Conceptual design would be good basis to decide on direct/indirect view
- SID will be different should we try to keep commonalities?
- Not heard from 4th concept yet.