

Turn-by-turn measurement at the ATF damping ring

Y. Renier , Y. Papaphilippou, R. Garcia

ECFA LC2013
28 of May 2013

Introduction

Analysis with
Sussix and
GetLLM

Measurement

Analysis
combining BPMs
with NAFF

Conclusion and
prospects

Headlines

Introduction

Analysis with Sussix and GetLLM

Measurement

Analysis combining BPMs with NAFF

Conclusion and prospects

Introduction

Analysis with
Sussix and
GetLLM

Measurement

Analysis
combining BPMs
with NAFF

Conclusion and
prospects

Headlines

Introduction

Analysis with Sussix and GetLLM

Measurement

Analysis combining BPMs with NAFF

Conclusion and prospects

Introduction


Analysis with
Sussix and
GetLLM

Measurement

Analysis
combining BPMs
with NAFF

Conclusion and
prospects

ATF Damping Ring at KEK



Parameter	Nominal value
ϵ_x	$1.0 \times 10^{-9} \text{rad.m}$
ϵ_y	$1.0 \times 10^{-11} \text{rad.m}$
Circumference	138m
Energy	1.3GeV
Intensity	$1.10^{10} e^-$

Turn-by-turn
measurement at
the ATF damping
ring

Y. Renier

Introduction

Analysis with
Sussix and
GetLLM

Measurement

Analysis
combining BPMs
with NAFF

Conclusion and
prospects

Turn by Turn Analysis

Motivation

- ▶ 96 new BPMs installed capable of turn by turn measurement.
- ▶ Few μm resolution.
- ▶ Fast measurement of β functions, coupling, ...
- ▶ Combine BPMs data to get tune measurement over few turns.

The Data

- ▶ Obtained in December 2012.
- ▶ Low intensity (may impact resolution)
- ▶ Parasitic measurements, no dispersion measurement.
- ▶ Injection data, exciter not used.

Headlines

Introduction

Analysis with Sussix and GetLLM

Measurement

Analysis combining BPMs with NAFF

Conclusion and prospects

Introduction

Analysis with
Sussix and
GetLLM

Measurement

Analysis
combining BPMs
with NAFF

Conclusion and
prospects

Analysis

Analyzing each BPM individually

- ▶ Tunes measurement with FFT (windows to reduce noise influence)
- ▶ with sussix or NAFF, measure resonances (amplitude and phase) for:
 - ▶ in horizontal plane: $(1, 0)_h$, $(0, 1)_h$, $(2, 0)_h$ and $(3, 0)_h$
 - ▶ in vertical plane: $(0, 1)_v$, $(1, 0)_v$, $(1, 1)_v$
- ▶ From resonance measurements, with getLLM we get:
 - ▶ Twiss functions from amplitudes or phases.
 - ▶ Coupling measurement.
 - ▶ f_{3000} (sextupoles induced resonances).
- ▶ Match model for experimental tunes, then compute response matrices.
- ▶ From β beating, phase mismatch and coupling, corrections are computed (based on response matrices).

Headlines

Introduction

Analysis with Sussix and GetLLM

Measurement

Analysis combining BPMs with NAFF

Conclusion and prospects

Introduction

Analysis with
Sussix and
GetLLM

Measurement

Analysis
combining BPMs
with NAFF

Conclusion and
prospects

Approximative tunes with windowed FFT

Turn-by-turn
measurement at
the ATF damping
ring

Y. Renier


Introduction

Analysis with
Sussix and
GetLLM

Measurement

Analysis
combining BPMs
with NAFF


Conclusion and
prospects



β_x function measurement

Turn-by-turn
measurement at
the ATF damping
ring

Y. Renier



Introduction

Analysis with
Sussix and
GetLLM

Measurement


Analysis
combining BPMs
with NAFF

Conclusion and
prospects

β_y function measurement

Turn-by-turn
measurement at
the ATF damping
ring

Y. Renier



Introduction

Analysis with
Sussix and
GetLLM

Measurement


Analysis
combining BPMs
with NAFF

Conclusion and
prospects

β_x beating measurement

Turn-by-turn
measurement at
the ATF damping
ring

Y. Renier



Introduction

Analysis with
Sussix and
GetLLM

Measurement


Analysis
combining BPMs
with NAFF

Conclusion and
prospects

β_y beating measurement

Turn-by-turn
measurement at
the ATF damping
ring

Y. Renier



Introduction

Analysis with
Sussix and
GetLLM

Measurement


Analysis
combining BPMs
with NAFF

Conclusion and
prospects

ϕ_x measurement

Turn-by-turn
measurement at
the ATF damping
ring

Y. Renier



Introduction

Analysis with
Sussix and
GetLLM

Measurement


Analysis
combining BPMs
with NAFF

Conclusion and
prospects

ϕ_y measurement

Turn-by-turn
measurement at
the ATF damping
ring

Y. Renier



Introduction


Analysis with
Sussix and
GetLLM

Measurement

Analysis
combining BPMs
with NAFF

Conclusion and
prospects


D_x measurement (done with NAFF)



$$2A_{Q_s} = D_x \frac{\Delta E}{E} \quad (1)$$

Correction

Y. Renier



Introduction

Analysis with
Sussix and
GetLLM

Measurement

Analysis
combining BPMs
with NAFF

Conclusion and
prospects

Headlines

Introduction

Analysis with Sussix and GetLLM

Measurement

Analysis combining BPMs with NAFF

Conclusion and prospects

Introduction

Analysis with
Sussix and
GetLLM

Measurement

Analysis
combining BPMs
with NAFF

Conclusion and
prospects

Combining BPMs

- ▶ Classical analysis : Fourier transform of



$$\begin{pmatrix} X_{BPM1}(turn\ 1) \\ \vdots \\ X_{BPM1}(turn\ 100) \end{pmatrix}$$

- ▶ Combining BPMs : the Fourier transform of

$$\begin{pmatrix} X_{BPM1}(turn\ 1) \\ \vdots \\ X_{BPM100}(turn\ 1) \end{pmatrix}$$

- ▶ f must be multiplied by the number of BPMs
- ▶ Tune measured in few turns with 96 BPMs !

Synchrotron Tunes Evolution







100 turns \simeq 50ns

Remarks

- ▶ Q_s has a low fractional tune (0.0051), at least 400 turns needed.
- ▶ Amplitude of the peak decrease slowly (Energy oscillations considered constant).

Tunes Evolution



100 turns \simeq 50ns

Turn-by-turn
measurement at
the ATF damping
ring

Y. Renier

Introduction

Analysis with
Sussix and
GetLLM

Measurement

Analysis
combining BPMs
with NAFF

Conclusion and
prospects

Chromaticity Measurement

On the tune evolution measurement we get ΔQ_x and ΔQ_y as the factor in front of the sinus.
The definition of the chromaticity is :

$$\begin{aligned} Q'_x &= \frac{\Delta Q_x}{\frac{\Delta E}{E}} \\ Q'_y &= \frac{\Delta Q_y}{\frac{\Delta E}{E}} \end{aligned} \quad (2)$$

We measured :

$$\frac{\Delta E}{E} = 2 * \frac{A_{Qs}}{D_x} \quad (3)$$

So we got :

$$\begin{aligned} Q'_x &= \frac{\Delta Q_x}{2 * \frac{A_{Qs}}{D_x}} = 0.41 \\ Q'_y &= \frac{\Delta Q_y}{2 * \frac{A_{Qs}}{D_x}} = 0.88 \end{aligned} \quad (4)$$

Headlines

Introduction

Analysis with Sussix and GetLLM

Measurement

Analysis combining BPMs with NAFF

Conclusion and prospects

Introduction

Analysis with
Sussix and
GetLLM

Measurement

Analysis
combining BPMs
with NAFF

Conclusion and
prospects

Conclusion & prospects

Conclusion

- ▶ Turn by turn data from ATF analyzed.
- ▶ Twiss functions measurements demonstrated.
- ▶ Correction of Twiss functions looks good.
- ▶ Tune measurement in about 30 turns possible.
- ▶ Chromaticity measured from energy oscillation.

Prospects

- ▶ Try correction experimentally at ATF.
- ▶ Check chromatic measurements.
- ▶ Finalize coupling correction.